

Starting Guide



TABLE OF CONTENTS

INTRODUCTION
Advance Steel
Where to find information?
INSTALLATION
System requirements
Starting the installation
STARTING ADVANCE STEEL
ADVANCE STEEL USER INTERFACE
Other important tools for using Advance
Advance Steel UCS
Accessing Element Properties
3D MODELING
Advance objects
Creating a building grid
Creating columns
Creating beams14
Straight beams14
Automatic Steel Connections
Accessing joint properties18
Creating a Clip Angle connection18
Copying a connection
Shear plate connection
Creating a base plate23
Creating a bracing25
Inserting a hand-railing27
Inserting Straight stairs
Inserting isolated footing
Clash check
NUMBERING





DRAWING CREATION	32
Drawing management	41
Opening the Document Manager	42
Create Shop Drawings	42
LIST CREATION	47
CNC DATA CREATION	50
RECOMMENDED PRACTICES	52
Saving the project	52
Modeling	52
Numbering	53
Creating drawings	54
Lists	54
NC files	54





INTRODUCTION

This starting guide is a brief introduction to working with Advance Steel, describing the basic methodology and not meant to replace formal training.

Advance Steel's model based environment allows you to produce accurate detailed general arrangement and shop drawings faster, helping to speed time to erection and fabrication.

The **Advance Steel objects** chapter describes the main objects to create a small steel structure.

Some of the Advance Steel connections are described in the **Automatic Steel Connections** chapter and are used to create a small model. The 3D model is created using a 1:1 scale. The model contains information about dimensions, objects, and attributes from which drawings are created as described in the **Drawing Creation** chapter.

The examples presented in this guide are generic for worldwide use and do not conform to local or specific company standards.

Since not all Advance Steel tools are described in this guide, refer to the <u>Advance Steel Help</u> for more details on all commands and parameters.

Advance Steel

Advance Steel is a leading edge steel construction application designed for steel professionals. It provides a simple user-friendly working environment for creating 3D structural models from which drawings are created.


The three dimensional model is created and stored in a drawing (in DWG format). The Advance Steel model forms the basis of the 3D construction. Complex structures are created using Advance Steel structural elements (e.g., a stairway) with all the required features, joints, and connections, within a command.

The Advance Steel model becomes the master reference for other tools:

- Dimensioned and labeled general arrangement and shop drawings are automatically created from the model.
- The Advance **Document Manager** manages all general arrangement and shop drawings. The update tool in the Document Manager makes single click drawing adjustments possible after model changes.
- Structured BOMs (bills of materials) and NC-information are also created from the model and include all model information such as part marks and quantities. The Document Manager also controls these documents.







All software tools described in this guide and all remarks related to the product pertain only to Advance Steel and for reading simplification only the generic name **Advance** is used.

Where to find information?

Advance has a help system that offers step-by-step instructions for every function.

To access the help:

On the right side of the Advance Steel 2018 toolbar, click ⑦ or use the **F1** key on your keyboard.

INSTALLATION

System requirements

To successfully install Advance Steel, certain requirements have to be met.

For more details, see the <u>Installation help</u>.

Starting the installation

Before installing Advance Steel 2018:

- Make sure you have administrator rights.
- Close all active Windows applications.
- Disable the antivirus.



STARTING ADVANCE STEEL

To start Advance Steel:


- Double click on the **Advance Steel** icon on the desktop.

Or

On the Windows task bar, click , then select All programs → Autodesk → Advance Steel 2018
 → Advance Steel 2018

ADVANCE STEEL USER INTERFACE

Advance Steel is fully integrated into AutoCAD[®]. Advance Steel panels are added to the AutoCAD[®] ribbon.




1. The Quick Access Toolbar

Provides fast access to the most frequently used tools. To add an Advance Steel tool to the Quick Access Toolbar, right-click the ribbon button and select Add to Quick Access Toolbar. The Quick Access Toolbar can be positioned above or below the ribbon.

2. The ribbon

Contains a collection of panels grouped on tabs, according to type. For easier access, the main tools are located on the **Home** tab. On the panels, tools are grouped on different rows and include large buttons for the most frequently used functionalities.







Some panels can be expanded by clicking the arrow on the bottom line.

	💥 Standard Grating
	💥 Bar Grating
	💥 Variable Grating, rectangular
🔆 Standard Grating	
🞇 Bar Grating	💥 Variable Grating, polygonal
💥 Variable Grating, rectangular	🗞 Grating at Polyline
Grating 🗖	-🖾 Grating

The ribbon can be minimized, thus enlarging the drawing area.

3. Tool palettes

Contain other tools, complementary to the functionalities available on the Advance Steel ribbon.

4. Command line

Allows Advance Steel commands to be entered using the keyboard. Press **<Enter>** after each entry.

5. Status bar

Displays information regarding the program status during different phases of the project. It also provides access to the configuration of certain parameters: snap modes, object tooltips content, current coordinate system, and working units.

Other important tools for using Advance

- To cancel a command, press the **Esc** key.
- The current command and prompts are displayed in the command line window at the bottom of the screen. Press the **F2** key to open and close the command line window.
- The right mouse click behaves like the **Enter** key.
- When the cursor hovers over a ribbon button, the button's tooltip appears.
- The Undo command on the Quick access toolbar cancels one or several commands.



• The **Match properties** command copies properties from one object to another. The transferred properties are selected from the given list.


Dimensions	Export & Impo	t Tools	Render	A360	Ad
R×		📕 Byl	ayer		•
Paste	Match		-ByLayer		•
*	Properties	=	— ByLayer		•
Clipboard		Properti	es 🔻		ы





Advance Steel UCS

Advance Steel objects are created in 3D-space using the appropriate tools and their orientation is dependent on the current User Coordinate System (UCS). To place the coordinate systems in the correct position use the Advance Steel UCS tool palette.



Accessing Element Properties

When you create an Advance Steel element, a dialog appears, in which different settings and drawing styles can be changed.

There are several ways to access the element properties:

• On the Tools tool palette, click



- Right-click the element and select **Advance Properties** from the contextmenu.
- Double click the element.





3D MODELING

Advance objects

Advance objects are created in 3D-space using various program tools. The object's orientation depends on the current UCS (**U**ser **C**oordinate **S**ystem).


Creating a building grid

The grid is useful for placing construction elements and for orientation in the 3D view. Placing grid axes is the first step of 3D modeling in Advance.

A building grid is created in the X/Y-plane of the current coordinate system and consists of two independent axis groups: in the X- and Y- directions. The grid axis tools are grouped on the **Grid** panel of the **Objects** tab.

₩	100	⊞₩			
∐	ሰ	₩ 🗄			
¦	2				
Grid					

Example: Building grid with 3 axes in the X-direction and in the Y-direction:



- 1. On the ribbon, click ^Ⅲ (Building Grid).
 - Home \rightarrow Objects $\rightarrow \ddagger$ (Building grid)
 - Objects \rightarrow Grid $\rightarrow \ddagger$ (Building grid)
- 2. Enter 0", 0", 0" on the command line to set the first point in the origin.
- 3. Enter 196", 196" to set the second point.

Next, modify the axes number in each group.





- 1. Select the X-axis group.
- 2. Right click and select **Advance Properties** from the context menu. The *Axes parallel* dialog box appears. All modifications are made here.

To modify the number of axes:


- 1. Click the **Group** tab.
- 2. Set the **Number** to **3**. Note that the distance value is automatically calculated. The new value should be **8' 2"**.

Advance Steel - N	OT FOR RESALE Axes, p	oarallel	
Total	Group index :	1	
Group	Definition		
Single axis	Number :	3 8' 2"	
Display type	Distance (D) :	02	
			1 2 3 4 5 6

The model changes dynamically as values are entered or new values are selected, providing instant visual feedback.


Repeat the same steps for the axes in the Y-direction.

Note: You can also change the label type to capital letters for the axes in the Y direction, for more clarity. You can do this by accessing the **Total** tab in the **Axes, parallel** dialog, and choosing "Capital letters" from the **Label type** drop-down.










Example: Adding an axis to the grid.

To add a single axis:

- 1. On the ribbon, click 🛄 (Single axis).
 - Home \rightarrow Objects $\rightarrow \prod$ (Single axis).
 - Objects \rightarrow Grid $\rightarrow \prod$ (Single axis).
- 2. Click where you want to add the axis and enter 0" on the command line to set the first point in the origin.
- 3. Enter 196" to set the second point. The *Axes, parallel* dialog appears:

In the Total tab, set the Label start to 4, to rename the axis index.
 Note: You will see that in the Single axis tab, the Axis index and Name will be automatically set to 4.




Next, extend the grid (the axis group created in the Y direction) to reach the newly created axis.





To extend an axis group:

- 1. On the ribbon, click \blacksquare (Extend axes).
 - Objects \rightarrow Grid $\rightarrow \blacksquare$ (Extend axes).
- 2. Select the boundary object, which in this case is the axis labeled with 4 and press Enter.
- 3. Next, select the axes that need to be extended (axes A, B and C), one by one, pressing Enter after each selection:



Creating columns

Columns are created directly in the model and are displayed, by default, in the *Wireframe* mode.

Columns are created as simple sections, compound sections, curved sections or welded sections. The column creation is performed using the **Column** command on the **Beams** panel, **Objects** tab.




The command can also be found in the **Objects** panel, on the **Home** tab.

Columns are simply placed in the model. You can place as many columns as you need. To exit the command press the *Esc* or *Enter* keys or right-click your mouse.


Example: Creating W12x26 columns.







- 1. On the ribbon, select iii
 - Home \rightarrow Objects $\rightarrow \emptyset$
 - Objects \rightarrow Beams \rightarrow
- 2. Place the columns where you need in the model. In this example they are placed at the grid intersections.



3. Right-click your mouse to exit the command.

The *Beam* dialog box appears. Select the section class (AISC 14.1 W), followed by the section (W14x48).



Advance Steel - N	OT FOR RESALE Beam [:	16]
Section & Material	Section	10]
Positioning	Section	► I Sections ► AISC 14.1 W ► W14x48 ►
Naming	Unwind profile	
Fabrication data		
User attributes		
Display type		
Behavior		
Properties		
Design Forces	Material	
Camber properties	Material	► Steel ► A992
	Coating	None
	Galvanizing	
	Construction class	None
	Detail class	None
	Confidence	None

Creating beams

Beams are created directly in the model and are displayed, by default, in the *Wireframe* mode.

In Advance, a variety of different beam types are available. Beams are created as simple sections, compound sections, curved sections or welded sections. The beam creation is performed using the tools on the **Beams** panel, **Objects** tab.




The most used beam creation tools are grouped on the **Objects** panel, on the **Home** tab.


Straight beams

Example: Creating W12x26 straight beams from the top of one column to another.






- 1. On the ribbon, select \mathbb{I} .
 - Home \rightarrow Objects $\rightarrow \mathbb{T}$
 - Objects \rightarrow Beams $\rightarrow \mathbb{T}$
- Select a *Node* snap point on the top of the first column.
 Note: Make sure the *Node* option is checked in the *Object Snap* menu.



3. Move the mouse pointer to the second column top.







4. Repeat the same steps for as many beams as you want to create and then press *Enter* to exit the command.

Note: For a continuous beam creation, use the **Continuous Beam** command from the **Objects** tab, **Beams** panel. Unlike the other beam creation commands, this one lets you select points continuously, not only creating objects defined by two points, one by one.

The *Beam* dialog box appears. Select the section class (AISC 14.1 W), followed by the section (W12x26).

Advance Steel - NO	OT FOR RESALE Beam [3	30]	- ×
Section & Material	Section	► Sections ► AISC 14.1 W ► W12x26	_
Positioning Naming	Unwind profile		
Fabrication data			
User attributes Display type			
Behavior			
Properties			
Design Forces	Material		
Camber properties	Material	▶ Steel ▶ A992	-
	Coating	None	•
	Galvanizing		
	Construction class	None	-
	Detail class	None	-
	Confidence	None	-

Automatic Steel Connections

Advance Steel helps you improve productivity by providing a parametric library of steel connections.




All individual joint elements, including their properties, are held together and represented as a gray box connection object.

Note: A structural element creates several Advance objects at a time (i.e., entire structures are created by simply clicking one button).


All parts of a structural element are related to each other and their height, position, section, etc., are changed in one step.

Joints are available in the **Connection Vault**, which is accessible from the **Extended Modeling** panel of the **Home** tab. The joints are grouped in categories according to the type of individual members.

Connection vault	∩ # ∏ 22 ≿ œ		0 10 In	Advance Steel Tool Palette
	Extend	led Mo	delina	



Frequently used joints can be grouped in the Favorites category for quicker access.







Accessing joint properties

To access the joint properties dialog:

- Double click on the connection object (the gray box).
- Select a joint element, right-click and Select Advance Joint Properties from the context menu.

\bigcirc	Rotate
	Draw Order
	Group +
	Advance Properties
	Advance Joint Properties
	Show Assembly CS
	Custom Connection Properties
	Explode to ACIS
•	Add Selected
R	Select Similar
* b	Deselect All

Creating a Clip Angle connection

The clip angle connects a beam to a column using an angle profile.

The tools for clip angle connections are grouped in the **Column - Beam** category of the **Connection Vault**.

	Platform beams	63	┦-※	S
	Clip angle)
	Clip angle - Skewed			
	Double side clip angle			
	Double-sided clip angle + end plate			
	Single side end plate			
	Moment end plate			
E	Extended Moment end plate			
	Moment Connection Beam to Beam			
X	Double side end plate with safety bolt			
F	Platform plate			


Example: Creating a clip angle connection.





- On the ribbon, click (Connection Vault).
 Home → Extended Modeling → (Connection Vault)
 Extended Modeling → Joints → (Connection Vault)
 Extended Modeling → Joints → (Connection Vault)
- 3. Select the column and right click.
- 4. Select the beam on which the clip angle should be created and right click.

The joint is created and the properties dialog appears. Modify the joint properties to suit specific requirements.



Copying a connection

Any previously created joint can be used as a template and copied with all its properties.

Example: Copying a clip angle.

- 1. Select any object created by the clip angle connection to be used as a template.
- 2. On the **Tools** tool palette, click [][[]] (Create by template).
- 3. Select the destination column and right click.
- 4. Select the corresponding rafter.




When a joint is copied, all its properties and logic relations are copied and the values for the joint are only entered once.

Zoom/Shade

To better view the created connection, use the **Zoom window** tool.

Note: You can find this tool in the Navigation Bar on the right side of your workspace. If the Navigation Bar is closed, you can open it, by going to the **View** tab \rightarrow **Viewport Tools** panel and clicking on the **Navigation Bar** button.

For a more realistic presentation of the model, use a shaded visual style. From the menus on the top-left corner of the drawing area select **Realistic**.




To cancel the shading, return to the **2D Wireframe** visual style.

Note: For a cleaner Realistic look, set the Visual Style to not show the Occluded Edges.

To do this:


1. Open the Visual Styles Manager, from the Viewtab.








- 2. Select the **Realistic** visual style.
- 3. In the settings box, go to **Occluded Edges** and make sure that the Show setting is set to No.






- Occluded Edges on.
- Occluded Edges off.

Cancel Zoom

To view the whole object, use the **Zoom Extents** tool. The entire frame is displayed.








Shear plate connection

The shear plate connects a column and a beam, using a single steel plate, welded to the beam and bolted to the column.

The tools for creating shear plate connections are grouped in the **Platform beams** category of the **Connection Vault**.



Example: Creating a shear plate.

Go to the beams you need to connect.



- 1. On the **Home** tab, **Extended Modeling** panel, click
- 2. From the **Platform beams** category, click I Shear plate
- 3. Select the column and right click.
- 4. Select the beam and right click.

The connection is created and can be modified in the properties dialog box.

	Advance Steel - NO	OT FOR RESALE Shear Plate [3]		×
\leq	Properties	Туре	Shear plate	-
	Properties	Name:		
	Library	Upgrade to master	V	
	Joint design Cuts & Stiffeners Plate & bolts Welds & Marking			
	Update now! V Aut	omatic Approval status	Not Set Not Calculated	

Creating a base plate

In this example, a base plate is created at the bottom of a column. The column is automatically shotened by the thickness of the base plate.

The tools for base plate connections are grouped in the **Plates at beam** category of the **Connection Vault**.






	Plates at beam	6	₽.	- ×
	Base plate			
	Tube base plate			
	Corner base plate			
	Base plate with traverse, bolted			
	Base plate cut			
	End plate			
E	Stiffener			
	Stiffener UCS			
<u>X</u>	Stiffener box Column			
P	Binding plates			
55				
×				

Example: Creating a base plate.

- 1. On the **Home** tab, **Extended Modeling** panel, click
- 2. From the **Plates at beam** category, select
- 3. Select the column and right click.

The base plate is created at the end of the column and can be modified in the properties dialog box. Both the column and the plate are welded together.





Creating a bracing


You can create a bracing, using the Bracing command on the ribbon.

To access the Bracing command:


1. Go to the **Extended Modeling** tab \rightarrow **Structural Elements** panel and click (Bracing).

Note: Bracing creation is UCS dependent, so make sure you set your UCS accordingly. Use the Move UCS tool, from the Advance Steel Tools Palette \rightarrow UCS category and set the UCS accordingly, to create the view in the XY plane.

To set the UCS on the correct plane, use the UCS tools in the Advance Steel Tool Palette, UCS category:




2. Create your bracing in the XY plane by selecting two diagonal points on the two columns.



3. The bracing is placed and the properties dialog box appears, where you can make any required modifications to your bracing.







Now you're ready to connect the bracing to the columns.

In this example, gusset plates at one diagonal will be created. The tools for connecting bracing members using gusset plates are grouped in the **General bracing** category of the **Connection Vault**.

	General bracings 🛛 🔞 🗄 🗕 🗙
	Gusset plate to column and base plate
	Gusset plate at one diagonal
	Gusset plate for 2 diagonals
	Gusset plate for 3 diagonals
Ē	Flat bracing with tension bolt
	Flat bracing with tension bolt and base plate
E	Flat bracing with tension bolt - 2 diagonals
	Bracing I Splice Plates Single
X	Bracing I Splice Plates Add Obj
M	Bracing I Splice Plates Double
X	Bracing I Splice Angle Single
Z	Bracing I Splice Angle Add Obj
	Bracing I Splice Angle Double

Example: Creating a Gusset plate at one diagonal connection.

1. On the **Home** tab, **Extended Modeling** panel, click




- 2. From the General bracings category, select V Gusset plate at one diagonal
- 3. Select the column to connect and right-click.
- 4. Select the **bracing beam** to connect and right-click.

The connection is created and can be modified in the dialog box.








Properties	Туре	Gusset plate at one diagonal	•
Properties	Name:		
Library	Upgrade to master	$\overline{\mathbb{V}}$	
Joint design		+ + * * d2 + + * *	
Standard		d1	
Additional connection			
Stiffener & Cover			

Repeat the steps for the other 3 connections.



Inserting a hand-railing

The Hand-railing command on the ribbon easily creates a hand-railing along a beam, between selected points. Simply select the beam and the points between which you want the railing to run and the hand-railing is automatically created.

Example: Creating a hand-railing on a selected beam.

- 1. On the Home tab, Extended Modeling panel or on the Extended Modeling tab, Structural Elements panel, click **#** (Hand-railing).
- 2. Select the beam and right click.
- 3. Select a start point and an endpoint for the railing and right click.





A message will appear, asking you if you want to select a nosing point relative to the start point.

Do	you v	vant to select a nosing point relative to the start point?
	Yes	
٠	No	

- 4. Select Yes or No:
 - If you select No, the railing is automatically created and the properties dialog appears.
 - If you select Yes, after you select the nosing point, the railing is automatically created and the properties dialog appears.
- 5. Make the necessary settings in the dialog box.

Advance Steel - NO	OT FOR RESALE Railing [409]	
Properties Properties Library	Type Name: Upgrade to master	Raling
Posts		
Handrail Post connection Hang off rail	omatic Approval statu	s Not Set

Inserting Straight stairs


You can easily create stairs; by using the stair creation commands (straight, spiral stairs or cage ladders) on the ribbon.

Example: Creating a straight stair between two points.

1. On the Home tab, Extended Modeling panel or on the Extended Modeling tab, Structural

Elements panel, click 🗳 (Straight stair).

2. You will have three methods to define the stair size: *Start and end point, Length and angle* or *Height and angle*. Choose the default *Start and end point* method by pressing **Enter**.




3. Select the start and end point of the stairs.











4. Choose the stair alignment (left, middle, right).



5. The stair is created and properties dialog box appears, where you can make the necessary settings.



Properties	Туре	Stair
Properties	Name:	
Library	Upgrade to master	V
Distances + Stringer Step - General Step - Top Step - Bottom		

Inserting isolated footing


Example: Creating an isolated footing under a column base plate.

To insert an isolated footing:


- 1. Go to the **Objects** tab \rightarrow **Other objects** panel and click \square (Isolated footing).
- 2. Specify the position of the footing or select a snap point to define its position under the base plate.







3. The isolated footing is created and the properties dialog box appears, where you can make the necessary settings.



Advance Steel - NOT FOR RESALE Isolated Footing [26]				
Shape & Material	Shape	Block		
Positioning	Length	2' 7 1/2"		
Naming	Width	2' 7 1/2"		
User attributes	Height	1' 3 3/4"		
Display type	Material	► Concrete ► C20/25		
Behavior				
benavior				

Clash check

A clash check tests if there are model interferences. Object interferences might be due to various modifications made to plates, bolts, members and their connections. This tool finds all interference cases so that they are fixed in the model before drawing creation.

The Advance **Clash Check** function checks selected elements or the entire model. Interferences are displayed as red collision solids and listed in a text window.

Example: Checking the created frame for interferences

1. On the Home tab \rightarrow Checking panel, click $\overset{\text{lic}}{\models}$ (Clash check).



The Clash check dialog box appears, containing the list of all collisions. If there are no collisions, the notification line displays "Collision check found no errors."

2. Close the window.





NUMBERING

The Advance numbering tool **automatically** numbers Single Parts and Assemblies for the entire model. The numbering finds **identical parts** that should have the same number.

The numbering procedure is a single button function and works on the entire model or on selected elements.

With automatic numbering all beams and plates obtain a single part mark. All other elements are classified as attached parts. The numbering for single parts and assembly parts is done in one step or separately. The numbering tools are grouped on the **Part marks** panel of the **Output** tab.



Example: Numbering single parts and assemblies in one step.

- 1. On the ribbon, click (Numbering).
 - Home tab → Documents panel, click
 - Output tab → Part marks panel, click _____
- 2. In the Numbering dialog select *Process single parts* and define the: Start value, Increment value, and Method of numbering.
- 3. Select *Process assemblies* and define the Method of numbering.

Numbering - Identical part detection					
General Special Standard Part Template					
Post number metho	Post number method None				
Preliminary mark	Preliminary mark				
Process Prelin	ninary mark				
Start	1				
Increment	1				
Single part					
Process single	e parts				
Start	1000				
Increment	1				
Method	SP: 1000,1001;MP:1,2,3	•			
Add zeros	2 -				
Format	%Prefix%MethodNumber	<<			
Assembly					
Process asser	nblies				
Start	1000				
Increment	1				
Method	SP: 1000,1001;MP:1,2,3	-			
Add zeros	2 👻				
Format	%Prefix %Method Number	<<			
	OK Cancel Apply	<u>H</u> elp			



The initial numbering gives temporary part marks such as B#*internal1001*. The final part mark 9s assigned after the Assembly and Single part drawings are created for those elements.

DRAWING CREATION

The 2D drawings are obtained after the design and numbering of the 3D model.

Advance Steel offers a variety of **drawing styles** for the creation of general arrangement drawings, section, and shop drawings in various designs.


A **drawing style** is a group of instructions used to create a detail drawing. It defines how the elements are displayed, labeled and dimensioned.

Drawing styles automatically create drawings with a layout configured exactly to the user's requirements. Drawing styles are used similarly to AutoCAD's dimension styles, line styles, etc.

The styles contain various settings (displayed parts, view, dimension, labeling, representation, etc.) in

database tables (libraries). Styles are available in the **Drawing Styles Manager** \bowtie) \rightarrow **Output** tab \rightarrow **Document Manager** Panel.

The preferred selection of the existing drawing styles, are displayed in the Drawing Style Palette.



The rules included in a drawing style can be modified. You can also define your own drawing styles.

The drawing style distinguishes between single parts and assemblies and it is used for drawing creation.


The tools for creating drawings are grouped in Quick documents Palettes




There are three Quick Documents palettes:

- 1. The Drawing Styles palette
- 2. The Drawing Processes palette
- 3. The BOM Templates palette

The palettes allow you to quickly browse and use drawing styles and drawing processes for drawing creations as well as list templates for BOM list creations. The categories are represented by intuitive images.









Example: Creating an isometric view.

Save the model prior to starting the drawing creation.

The viewport of the created view depends on the active user coordinate system (UCS). The view direction is against the Z-direction of the UCS.

1. To create an isometric view, click on the **UCS** tool palette and place the UCS in the plane of the screen.




2. On the Home tab, Documents panel, click 🐷 (Drawing Styles Palette) or on the Output tab,




Documents panel, Styles

3. The **Drawing Styles** tool palette appears. In the *1* – *GA 3D View* category, choose one view type (e.g. *1* – *GA 3D View* – *Model* – *w/o Labels*).



4. The Create detail dialog box appears. From this dialog you can choose between two options to create the detail.





- 5. Choose Modify settings.
- 6. In the Select destination file dialog \rightarrow New drawing tab:
 - a. Name your drawing: e.g. Isometric view.
 - b. Change the scale to 1/4"=1'-0".
 - c. Set a path for a separate DWG in which the detail is placed.

A Select destination file		- • ×		
New drawing Detail box Pro	totype (template) Existing drawings			
Drawing number	Isometric view			
File name	C:\ProgramData\Autodesk\Advance Steel	Browse		
Scale	1/4"=1'-0" 🗸			
Switch off level symbols				
Switch off weld symbols				
Switch off building axes/g	jrids			
Switch off hidden lines				
Switch off clipping				
Switch off hole representation				
<u> </u>				
<u>0</u> K	<u>C</u> ancel <u>H</u> elp			

7. In the Select destination file dialog \rightarrow Prototype template tab, select the prototype template:


A Select destination file	- • •
New drawing Detail box Prototype (template) Existing drawings	
 Shared ASDETPROTO.dwg ASDETPROTO-ANSI-A.dwg ASDETPROTO-ANSI-A.PORTRAIT.dwg ASDETPROTO-ANSI-B.dwg ASDETPROTO-ANSI-C.dwg ASDETPROTO-ANSI-C.Anchor plan.dwg ASDETPROTO-ANSI-D.Anchor plan.dwg ASDETPROTO-ANSI-E.dwg ASDETPROTO-ANSI-E.dwg ASDETPROTO-ANSI-E.dwg ASDETPROTO-ANSI-E.Anchor plan.dwg ASDETPROTO-ANSI-E.Anchor plan.dwg ASDETPROTO-ANSI-E.Anchor plan.dwg ASDETPROTO-ANSI-E.Anchor plan.dwg ASDETPROTO-ANSI-E.Anchor plan.dwg ASDETPROTO-ANSI-E.Anchor plan.dwg ASDETPROTO-ASsembly-ANSI-A.dwg ASDETPROTO-Assembly-ANSI-A.dwg ASDETPROTO-Assembly-ANSI-C.dwg 	E
<u>QK</u> <u>C</u> ancel <u>H</u> elp	





8. Click **OK** to close the dialog box.

The drawing is created and saved as .dwg in the specified path:



Example: Creating an Anchor plan view.


Save the model prior to starting the drawing creation.

The viewport of the created view depends on the active user coordinate system (UCS).

1. The view will be created in the XY plane. Set the UCS to correspond to the view direction, like in the image below:








2. Go to the Home tab, Documents panel, click 📴 (Drawing Styles Palette) or on the Output tab,

Documents panel, click ^{Drawing} Styles

3. The **Drawing Styles** tool palette appears. In the *3* – *GA Plans, Elevations / Sections* category, choose one view type (e.g. 3 – *Anchor Plan – grid & holes dimensioned*).




- 4. The Create detail dialog box appears. From this dialog you can choose between two options to create the detail.
- 5. In the Select destination file dialog \rightarrow New drawing tab:

- a. Name your drawing.
- b. Change the scale to 1/4''=1'-0''.
- c. Set a path for a separate DWG in which the detail is placed.
- 6. In the Select destination file dialog \rightarrow Prototype template tab, select the prototype template.
- 7. Click **OK** to close the dialog box.
- 8. Select two diagonal points to define the area of your view.

Note: For a more accurate orientation, select a Top view of the model.








9. Click OK.

The drawing is created and saved as .dwg in the specified path.



Example: Creating an Elevation view.


Save the model prior to starting the drawing creation.

The viewport of the created view depends on the active user coordinate system (UCS).

1. The view will be created in the XY plane. Set the UCS to correspond to the view direction, like in the image below:








2. Go to the Home tab, Documents panel, click 🔛 (Drawing Styles Palette) or on the Output tab,



Documents panel, click Drawing Styles


3. The **Drawing Styles** tool palette appears. In the *3* – *GA Plans, Elevations / Sections* category, choose one elevation view type (e.g. 3 – *Elevation View* – *Full*).



- 4. The Create detail dialog box appears. From this dialog you can choose between two options to create the detail.
- 5. In the Select destination file dialog \rightarrow New drawing tab:
 - d. Name your drawing.
 - e. Change the scale to 1/4"=1'-0".
 - f. Set a path for a separate DWG in which the detail is placed.
- 6. In the Select destination file dialog \rightarrow Prototype template tab, select the prototype template.
- 7. Click **OK** to close the dialog box.
- 8. Select two diagonal points to define the area of your view.








9. Click **OK**.

The drawing is created and saved as .dwg in the specified path.



Drawing management

The **Document Manager** is used to preview, manage and erase the created details in separate drawings (DWGs).

The link between the model and the drawing is managed automatically. Advance Steel automatically detects the details that require updating due to model modifications. The **Document Manager** also controls drawing updates.

The **Document Manager** controls all dependent details and lists all information (e.g., which model drawings have been created and how many). More than one detail can be stored in a single DWG. The **Document Manager** tree structure shows the details that are in each DWG.





Opening the Document Manager

• On the Home tab, Documents panel, click



• On the **Output** tab, **Documents** panel, click

A Document Manager		- • •
Project documents Details Up to date Cevasion.dwg C	Properties Preview	Force update Update Revision Revision Delete Not Set Add to batch plot Add to explode Change prototype Open drawing W Automatic detail status check
Status check	OK Cancel Help	Warning: If this option is not selected, then the drawing status is

The Document Manager lists all the created drawings, bill of materials / structured BOMs and the NCdata created from the model. The documents are displayed on the **Preview** tab.


Create Shop Drawings

Example: Creating a single part plate drawing using a drawing style.


To create a single part detail drawing:

- 1. Go to the **Output** tab \rightarrow **Document Manager** panel and click **(Drawing stylemanager)**.
- 2. In the Drawing Style Manager window, select the desired drawing style, in this case *Sp-Plate*.
- 3. Click Use.






4. Identify and select the model objects you need to detail and right-click.



- 5. The Create detail dialog box appears. From this dialog you can choose between two options to create the detail.
- 6. If you choose Modify settings, you can choose a destination for your detail drawing, the scale and a prototype. Click OK to close the dialog.
- 7. Your detail drawing is created and saved as a .dwg file in the specified location. You can either open it from the specified location or right-click on the model object and select *Show part detail*.







Example: Create a shop drawing with plates, using a drawing process.

To do this:

- 1. Go to the **Output** tab \rightarrow **Document Manager** panel and click \mathbb{P} (Drawing processmanager).
- 2. In the Drawing Process Manager window, select the desired drawing process, in this case *All Sp Plate PageFull ANSI-E*.
- 3. Click Use.





A Drawing Process Manager	
Image: Section 2016 (Section 2016) Image: Sectio	Main definition Additional steps Main step Step definition Objects selection Model objects: All Sp Objects selection And and arwing(s) Filename selector: ANSI-E Singlep Scales Alternative scales: 11/2"=1-0", 1 Special scales for selection views None Selection views None Selection views None Selection views None Selection Conjug for views None Selection Conjug for views None Selection Model opjects: Main step Main step Main step Main step Main step All Sp PageFul Main step All Sp PageFul Main step All Sp Selection Model objects: All Sp Selection Model objects: None Main step All Sp PageFul Main step Main step Main step Main step All Sp Main step Main step Main step All Sp All Sp Main step Main step Main step All Sp Main step Main step Main step Main step All Sp All S
⊕ - I → I → Sp PageFul ANSI-C ⊕ - I → I → PageFul ANSI-D ⊕ - I → I → PageFul ANSI-D ↓ → I → A → PageFul ANSI-E ↓ → A → Additional Steps ⊕ - I → Additional Steps	Drawing styles Detail style map: 07 - Singlepart
⊕ ⊕ Alsop Pagerul Legal ⊕ ⊕ Alsop Pagerul Legal ⊕ ⊕ Alsop Pate Each ANSI-A ⊕ ⊕ Alsop Pate Each Legal ⊕ ⊕ Alsop Pate Pagerul ANSI-C ⊕ ⊕ Alsop Pate Pagerul ANSI-D	•
	Use OK Cancel Apply


4. In the next window, click OK.

All Sp			•
	Plate thickness [mm] Part mark	Minimum	Maximum
rawing number	Drawin	Drawing number g number increment	1000 1
rrangement	by position, ascending	19	
elect existing dra	wings to use for the det	ailing process:	

5. Your detail drawing is created and saved as a .dwg file in the *Details* folder; in the same location your model is saved. You can either open it from that location or you can right-click on any of the detailed model objects (in this case, on any plate) and select *Show part detail*.







Note: If an object is detailed on more than one drawing, you will have more options to choose from in the Show part detail contextual menu:



N	Repeat ASTORMULTIEDIT Recent Input		
	Recent input	·	
	Clipboard	•	
	Isolate	•	
/	Erase		-
- -	Move		
0	Copy Selection		
	Scale		
\diamond	Rotate		
	Draw Order	- F	
	Group	•	
	Advance Properties		
	Advance Joint Properties		
	Show Assembly CS		//// J/4
	Custom Connection Properties		
	Show part detail	•	1000
	Explode to ACIS		[SP] 1001
• ₅	Add Selected		
arg	Select Similar		

LIST CREATION


To quickly create a Bill of Material list you need to access the preferred BOM templates, using the Quick Documents - Bill of Material template.

- 1. You can open the Quick Documents BOM template palette:
- Home tab → Documents panel → ^{IF BOM Templates}
- Output tab → Documents panel → Templates
- 2. To create a list, click on any of the available templates.

Note: You can also preselect objects in the model, and the BoM template list will be created only for the objects in the selection.







Once the list is created, it will be opened in the BOM Viewer and can be saved and registered to the model.

To add or remove BOM templates from the **User** category of BOM templates - Quick Documents palette, you need to set the status of the checkbox associated to the BOM template list in the **BOM Editor**.

Note: Change palette content category - Advance / User / Country: You can switch between categories by clicking the first icon on the palette title bar - the content of the palette will change depending on the chosen category:

Drawing styles 🕥 🗄 🕂 💥

The icons differ for each category:

Drawing styles	🚳 🗄 🕂 💥
Drawing styles	<u>↓</u> @ ! +×
Drawing styles	🔲 🖗 🗄 🕂 💥





Part lists	Template Editor: A	eticle list - 105				Part lists 🙎 🙆 🕴 🗕 💥
Artce Ist		6 0 x / e a / 9, 9, 	100% ·	HORSEN SALES		Article lat
Deam list	ActiveReports 6	Namo	Кеу	Advance Template	R	Beam 1st
Eesm take-off list	A Label	Aticle list	105 101 118	Bit of Materials H Contentials H Contentials Katerials		Beam take-off list
Curved beam list	CheckBox PichTextBox	Cladding list	106 102 104	Patists =		Cledding list
Grating fst	Shape	Crating lat Crating lat Material lat Material lat summary	113	Beam list Beam list Cadding list	-	Curved beam list
Material (st	/ Line	Plate list	103 115 116	Curved beam list		Grating list
Material list summary	H PageBreak	Saw list	116 117	Material list		Material list
Plate list	SubReport SubReport WeOthirect			Plate lat +		Material list summary
Preliminery list	Ht. ChatControl			Appearance +		Plate list
Saw ist	+ CrossSectionLine			ShowParame True Watermark (Preliminary list
Saw (st pictures				ViteormarkP ViteormarkS Clip		Saw list
				Appearance		Saw list pictures
			1/mi OK	Cancel		
			Current selection: ARM	Vet Document		

Example: Create a Material List.

- 1. Home tab \rightarrow Documents panel \rightarrow \implies BOM Templates
- 2. The **BOM Templates** palette appears.



3. From the **Part List** category, select **Material List**.

The *Material List* appears. It can be printed, saved, exported to PDF (and other formats) or sent by e-mail using the corresponding icons on the menu bar.



Α	AUTODESK [®] ADVANCE STEEL

		🔒 🛼 100 % 🔹 🖸 🚺 1/4	Backward S Forv				
		2		6	7	8 1	9 10
			Compa	iny			
	AUIC)DESK°	Client:	•	10	Job No:	
		ANCE STEEL	Project:		194 195		2
			Detailer:			Date:	30-Mar-16
Quantity	Mark	Description	Length	Grade	Part weight	Total weight	Remark
			(inch)	(inch) pound	pound		
		Beams					
6	1003	FL10X4	1 1/2"	A992	0.03	0.16	
1	1009	R042.4X4	1/8"	A992	0.03	0.03	
6	1019	FL10X4	1 9/16"	A992	0.03	0.16	
1	1020	RO42.4X4	6 7/16"	A992	1.37	1.37	
1	1021	RO42.4X4	4 11/16"	A992	0.99	0.99	
1	1022	R042.4X4	10 15/16"	A992	2.32	2.32	
1	1023	RO42.4X4	15' 8 3/4"	A992	40.03	40.03	
1	1024	RO42.4X4	1' 1/4"	A992	2.60	2.60	
16	b1000	RO42.4X4	3' 5 3/8"	A992	8.77	140.38	
2	b1005	RO42.4X4	5 5/16"	A992	1.13	2.26	
1	b1013	RO42.4X4	11 13/16"	A992	2.51	2.51	
1	В	W12x26	9' 10 3/4"	A992	257.33	257.33	
30	B1000	L1 1/4X1 1/4X1/8	10"	A36	0.85	25.37	


- 4. Click **Export**. The *Report export* dialog appears displaying the export options.
- 5. Select an export format from the list.
- 6. Click **OK**.
- Save the created BOM file. A file name is requested in a new window. The BOM file is saved as a Report in the ... \[model folder] \[model name] \BOM \[BOM filename] folder.

CNC DATA CREATION

Advance Steel produces CNC files (DSTV format) for workshop machinery directly from the 3D model. You can either select one model object or the entire model to create these types of files.

You can access the commands for the CNC data creation from:

- The **Output** tab → **NC&DXF** panel
- The Home tab → Documents panel




Example: Create an NC file for a selected model object.

1. Select a model object.








- 2. Go to:
 - The **Output** tab → **NC&DXF** panel and click ^{INC}
 - The Home tab → Documents panel and click ^{IIC}
- 3. The NC file is created and is saved in the **DSTV** folder that is automatically created in the same location as you model DWG.

Command:	stM4CommCreateNCByStyle 1	
	es have been created successfully	
🛛 🗙 🔧 💽 🕶 Type a		
O ♥ U C:\ProgramData\A	Autodesk\Projects\Industrial Example\DSTV\NC	
Organize 👻 📄 Open 🕴	New folder	
🔆 Favorites	Name	Date modified
	C1007.nc	8/6/2015 6:19 PM
🧮 Desktop	C1007.upd	8/6/2015 6:19 PM

You can also access the NC files, using the **Document Manager**, where you can see a preview of the file.





This small exercise was a very simple introduction to Advance Steel. In time, your familiarity, speed, and understanding of the power and versatility of Advance Steel will improve, as you use the software on real projects.

RECOMMENDED PRACTICES

Saving the project

 Create a folder structure to store your projects in correctly, create a projects folder and then create sub folders for each project.
 In that folder store the model which then creates its own relative folder and required sub

folders. This keeps all models and databases separate and avoids conflicts.Create an AutoSave folder location and adjust your system to save your automatic backup files to that known location, keep it simple and at the root of the System such as

3. Save your model at regular intervals.

C:\AdvanceSteel\Autosave.

4. Use a suitable Name for the Model such as the contract number, project reference or place name. This can be useful later on in the project, as the model name can be listed in the drawing and NC naming and also be linked to the actual file references.

Modeling

- 5. Always start your model at 0, 0, 0 in the World Coordinates.
- **6.** Be aware of how you model a beam/section "Right to left" or "left to right", as this can influence how the front and the back of beam are displayed on an assembly drawing.
- **7. Columns** Always try to model so the Z Axis of the column flange is to the outside face of the building for perimeter columns.
- **8.** System-line placement When modeling horizontal members, roof members, floor beams, etc. always try to have the system line in the top of the profile at the middle of the flange. This affects the assembly drawing dimensioning.

For Columns try to keep it in the center, unless you have a specific need for one column flange face to be at a set location, as this means that if you change section then the change in size goes away from that face. So the flanges still remain in line. This is sometimes used where cladding is applied directly to hot rolled steel flanges.

For purlins and rails, try to keep the system line to the bottom face nearest the supporting beam, as then if the size changes for the rail, the difference goes outwards, rather than altering the hot rolled frame set-out.

Always try to make sure your system lines meet for beams columns, etc. This is like you wire-line in the model and with this it is easy to check the primary position of an object, also the system line is used as the datum for the dimensioning of the Drawings and in other aspects of the modeling.

9. Remember your UCS; this is a vital tool in placement and orientation of objects within the Advance Steel environment.



- **10.** For complex setting out of a building, say radial, always try to have some reference/construction line geometry in the system, create a layer and place it in there, it can be turned off, but it is always there for reference.
- **11.** Before you model a beam type, like poly-beam, or curved beam, consider how you are going to manufacture it and more importantly how you are going to detail it.
 - > For simple curves use curved beams, rather than poly beams
 - For complex beams, that may appear too easy to create as poly beams, look at how the original shape line is created. If it is from a series of curves of known radii, model it as a series of curved beams as you will buy it as curves and then weld or joint together. Polybeams do not lend themselves to being dimensioned as radii; they work on points based upon the references they were created from.

KEEP IT SIMPLE - SIMPLE TO MODEL = SIMPLE TO MAKE.

- 12. Note the difference between holes and contours, make a decision on how the hole will be produced, drilled or cut out via cutting torch or profiler. This affects drawings and NC processing. For drilled holes use the Hole commands. For profiled holes use the Contour commands. The size of the hole makes no difference to how the NC describes it.
- **13.** Assess your project before you start, look at how you are going to build the structure, how it is going to be delivered, where you are starting from, craneage, etc. You can model it in Advance Steel, but you are the one driving it, it goes where you steer it.
- **14.** Try to use Macros where possible for Joints. When using macros, if you create a joint and think you may use it again somewhere, store it in the table with a suitable reference. For example bracings, you can set one up for Flats and one for Tubes, save each to the table and then when inputting bracing you can just select that default.
- **15.** Use the Project Explorer to manage the model structure, set up views so it's easier to work on plan or elevation at a time.
- **16.** Always use model roles, as this defines the prefix in numbering and also has influence with the drawing output. The drawing styles link to the Model roles to set the style within the process.

Numbering

- **17.** Use the standard numbering rules set in Advance Steel and try to work with those, always let the program to update the model numbering, DO NOT MANUALLY NUMBER UNLESS YOU HAVE TO, this can lead to problems.
- 18. If the model is not complete, then try numbering using the Lot/Phase option with the box checked. This means that the existing part of the model will have unique numbers. These numbers will not be used elsewhere in the model in later phases. This means you can carry on modeling and then just renumber at a later stage and numbers / items from phase 1 will not alter their numbers.
- **19.** Use the preliminary numbering of the model; adjust the BOM lists to include preliminary numbers. These references never change and can be a good way to track items whose final



number has changed. For example, if you pre order curved beams, this reference can be used to track that component.

Creating drawings

20. GA Drawings

Think about what you want before you start; map out how you are going to approach the drawings. For example, floor plans first in level order, from ground up, then Elevations going around the building, Sections through the building, local details of special joints / typical joints, 3D Views of model. Lot phasing 3D views.

Plan it on a piece of paper, make a list, assign the drawing numbers for GAs to follow this pattern, so you may have 5 drawings for plans, 4 for sections, etc.

Think about the SCALE on the paper, if you can combine two elevations onto one drawing, etc.

21. Part Drawings

Think about how they are going to be manufactured – in house, sub contracted off profilers, etc. All ordered in at once or in phases. This may change the paper size you choose to produce the drawing on. A3 or A4 single item puts each part on its own drawing, makes it easy to send, each drawing is relative to each part and that part only.

22. Assembly Drawings

Think about how they are going to be fabricated – all in one shop, subcontracted to various workshops, in phases, etc. Sometimes it is easier to create single drawings for each assembly, as they can be fitted onto smaller A3 size, most small fabricators only have limited printing facilities, and so sending A1 drawings can mean that they print at a vastly reduced size leading to mistakes, omissions or lots of phone calls to clarify what something is. So set up to smaller sheet to start with a larger scale to show the details clearer.

23. Check the drawings – sometimes things get missed or mixed up in the model, and are not always picked up. Use the drawings to check what is being produced. A quick review can save you time and money in the long run.

Lists

24. Filter the model to produce lists for required items; use the lists that are set for Curved Beams, plates, beams. Use the list to check the model and that you have done all the drawings and things are not missed.

NC files

25. If you want only plates of a certain size then use the search filter to find and select them, then create the NC files. You can adjust the naming of the files and details shown on the hard stamp to include things like thickness, number, using the defaults.





- **26.** Be aware of the Defaults in the Management Tools application; there are many settings there that can be adjusted to change the outcome of drawings and modeling, depending on your requirements.
- **27.** When building onto an existing structure this can be modeled in Advance Steel, but you must remember to set that structure so that it is not used for the Drawings or BOMs. These settings are on the **Behavior** tab in the object properties dialog. What this does is to set it so that when the model is numbered, these existing components are numbered but with a negative value and are not considered for drawings or material lists.

